Sandwich Wrap Label Dispenser Instructions


Placement

Place the label dispenser next to your sub wrap for easy access as shown below.

How to load the dispenser




Take the metal rod off of the dispenser and feed the rod through center roll of labels. Place rod back in grooves on dispenser.



Next, take the very end of the roll and feed the end piece of the sheet under the very first metal bar as shown.




After the edge is fed under the first bar, proceed to feed the paper edge over the 2nd bar and continue to feed the edge under the roller spool.



Once the edge has been fed underneath the roller spool, pull the edge of the paper until the label starts to peel off. Remember to trim the paper waste often to keep neat appearance.



Make sure to remove the label by the tab located on the bottom of the label as there is no adhesive on the tab.



DO NOT grab the entire label as your gloves will stick to the adhesive on the label.

© 2022 Subway IP Inc. Operations - 1/11/2022